







PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.

SHELTER 185×254



4×40 × 50

4×50 × 320





5×70 × 35

6×140 × 50

M8×70 × 12

1,4×40 × 15

LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.





MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%

ATTACH FOUNDATION BEAMS WITH SCREWS.




SHELTER 185×254

6×140 × 6
Ø 5 mm



LAY OUT THE **BOTTOM** LOGS,
ATTACH TO THE FOUNDATION.

SHELTER 185×254




THE WALL **LOGS** WILL HANG OVER
THE FOUNDATION **BEAMS** BY
APPROXIMATELY 5MM. THIS OVERHANG
IS DESIGNED AS A RAIN DRIP. **7%**


ATTACH THE FIRST ROW OF
WALL LOGS INTO THE BOTTOM
LOGS WITH **SCREWS**.

6x140 × 9

Ø 5 mm




SHELTER 185x254



AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.



SHELTER 185×254



INSTALL THE FLOOR BEAMS AND ATTACH THEM WITH SCREWS.

SHELTER 185×254



6x140 × 8
Ø 5 mm



INSTALL THE FLOOR BEAMS AND ATTACH THEM WITH SCREWS.


SHELTER 185×254

5×70 × 22
Ø 4 mm



DON`T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.

SHELTER 185×254






INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

SHELTER 185×254

6×140 × 6




Ø 5 mm



INSTALL THE ROOF PURLINS AND ATTACH THEM WITH SCREWS.


SHELTER 185×254

6×140 × 10
Ø 5 mm




PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE END OF THE **PURLINS** AND ATTACH WITH 10 SCREWS, 5 INTO **EACH** NEXT, SAW THE LAST **BOARD** TO MAKE IT FIT.

4x50
× 165





SHELTER 185×254




10 SCREWS INTO THE FIRST FLOORBOARD, 5 INTO EACH NEXT.

4x50
× 125





SAW THE FLOORBOARDS
WHERE NEEDED.

SHELTER 185×254






FB2



ATTACH FLOOR REINFORCEMENTS INTO THE FLOORBOARDS AND FASCIA TRIMS INTO THE ROOF PURLINS.

SHELTER 185×254

5×70 × 2 4×50 × 12
Ø 4 mm Ø 3 mm






EAVES EDGES GO ON TOP OF THE ROOFING*.

*(NOT INCLUDED)

SHELTER 185×254

4×40 × 43


Ø 3 mm



SAW THE **BASEBOARDS**
AND ATTACH WITH NAILS
AT **EVERY 0,5** METERS.

1,4X40
× 15

SHELTER 185×254





BB

DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x70 × 12

Ø 8 mm



WHEN THE **SLEEPING SHELTER** IS ASSEMBLED,
YOU SHOULD **COVER** THE TIMBER WITH
WOOD PROTECTIVE SEAL, PAINT OR **STAIN**
AS SOON AS POSSIBLE TO AVOID DETERIORATION
TO THE **WOOD**.

SHELTER 185×254

