












PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.



FRIDA 28



LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.






FRIDA 28



MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%




LAY OUT THE **BOTTOM** LOGS,
ATTACH TO THE FOUNDATION.

FRIDA 28




THE WALL **LOGS** WILL HANG OVER
THE FOUNDATION **BEAMS** BY
APPROXIMATELY 5MM. THIS OVERHANG
IS DESIGNED AS A RAIN DRIP. **5%**

ATTACH THE FIRST ROW OF
WALL LOGS INTO THE BOTTOM
LOGS WITH **SCREWS**.





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

FRIDA 28




SLIDE THE DOOR IN,
ATTACH THE HANDLE.

FRIDA 28



DON`T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.



FRIDA 28



INSTALL THE **BAR COUNTER**
SUPPORT AND **ATTACH** THEM
WITH SCREWS.

FRIDA 28


6x140 × 4
Ø 5 mm





INSTALL THE **BAR COUNTER** AND **ATTACH** IT WITH SCREWS.

6x140 × 4

Ø 5 mm





FRIDA 28



DETACH THE LATH FROM THE
BOTTOM OF THE KIOSK HATCH




FRIDA 28



SLIDE THE KIOSK HATCH IN,
ATTACH THE HANDLES.33%

INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

6x140 × 4
Ø 5 mm





FRIDA 28


INSTALL THE **ROOF** PURLINS AND **ATTACH** THEM WITH SCREWS.

6x140  × 6

Ø 5 mm 





FRIDA 28



PLACE THE FIRST ROOFBOARD FLUSH WITH THE END OF THE PURLINS AND ATTACH WITH 6 SCREWS, 3 INTO EACH NEXT, SAW THE LAST BOARD TO MAKE IT FIT.



4x50  x 192



FOR THE FASCIA TRIMS INSERT
SCREWS AFTER EVERY 0,5 METERS.

FRIDA 28

4x40
× 28





EAVES EDGES GO ON TOP OF THE ROOFING*.


*(NOT INCLUDED)

4x40 × 32

Ø 3 mm





FRIDA 28



ATTACH ROMBS WITH SCREWS.




FRIDA 28

4x40 × 4
Ø 3 mm





12 SCREWS INTO THE FIRST FLOORBOARD,
6 INTO EACH NEXT, SAW THE
LAST BOARD TO MAKE IT FIT.

4x50
× 162



SAW THE **BASEBOARDS**
AND ATTACH WITH NAILS
AT **EVERY 0,5** METERS



1,4x40
× 30




DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x60 × 12

Ø 8 mm






FRIDA 28



WINDBOARD


IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90°.

FRIDA 28



IF **DOORS** ARE IN DIFFERENT HEIGHTS
OR THERE IS A GAP **BETWEEN** THEM,
ADJUST 3 SCREWS ON DOOR HINGES.

FRIDA 28



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

FRIDA 28

