




PREPARE THE **GROUND**, UNWRAP THE **PACKAGE**,
LAY OUT THE **COMPONENTS**, FIND THE **TOOLS**.

STANDARD



4x40



4x50



5x70



6x140




M8x70





1,4x40



LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.



STANDARD



MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%

LAY OUT THE **BOTTOM** LOGS,
ATTACH TO THE FOUNDATION.



STANDARD

5x70

Ø 4 mm

6x140

Ø 5 mm



THE WALL **LOGS** WILL HANG OVER
THE FOUNDATION **BEAMS** BY
APPROXIMATELY 5MM. THIS OVERHANG
IS DESIGNED AS A RAIN DRIP. **5%**


ATTACH THE FIRST ROW OF
WALL LOGS INTO THE BOTTOM
LOGS WITH **SCREWS**.

5x70



Ø 4 mm

6x140

Ø 5 mm




STANDARD




AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

STANDARD




SLIDE THE DOOR IN,
ATTACH THE HANDLE.

STANDARD




DON'T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.

STANDARD



SLIDE THE WINDOW IN,
ATTACH THE HANDLE.

STANDARD




INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

6x140

Ø 5 mm




STANDARD




INSTALL THE ROOF PURLINS AND ATTACH THEM WITH SCREWS.


6x140
Ø 5 mm



STANDARD



PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE END OF THE **PURLINS** AND ATTACH WITH SCREWS, SAW THE LAST **BOARD** TO MAKE IT FIT.




STANDARD



FOR THE FASCIA TRIMS INSERT
SCREWS AFTER EVERY 0,5 METERS.

4x40



STANDARD




EAVES EDGES GO ON TOP OF THE ROOFING*.
*(NOT INCLUDED)

STANDARD

4x40

Ø 3 mm




ATTACH ROMBS WITH SCREWS.

STANDARD




4x40

Ø 3 mm



STANDARD

4x50





SAW THE **BASEBOARDS**
AND ATTACH WITH NAILS
AT **EVERY 0,5** METERS.



1,4x40



STANDARD



WINDBOARD CONNECTS BOTTOM LOG WITH THE TOP LOG. **SAW THE WINDBOARD** INTO THE **RIGHT** LENGTH. FOR THE TOP BOLT, DRILL **8MM HOLE** THROUGH THE WINDBOARD.



STANDARD




WINDBOARD

DRILL THROUGH THE **WALL**, HOLE **MUST** BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLTS. 97%


IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90° .

STANDARD



IF **DOORS** ARE IN DIFFERENT HEIGHTS
OR THERE IS A GAP **BETWEEN** THEM,
ADJUST 3 SCREWS ON DOOR HINGES.

STANDARD



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

STANDARD

