




PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.



STANDARD



4x40



4x50



5x70





6x140





M8x70



LAY OUT THE **BOTTOM** LOGS
AND **SQUARE** IT BY MEASURING
FROM CORNER TO **CORNER**.



STANDARD




MAKE **SURE** THAT THE BOTTOM LOGS
ARE INSTALLED ON A **LEVEL** SURFACE.
CHECKING ALL DIRECTIONS,
INCLUDING **CORNER** TO CORNER. **2%**



ATTACH THE LOGS
WITH SCREWS.

5x70

Ø 4 mm



STANDARD






ATTACH THE FIRST ROW OF
WALL LOGS INTO THE BOTTOM
LOGS WITH **SCREWS**.

5x70

Ø 4 mm


6x140

Ø 5 mm




AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

STANDARD




SLIDE THE **DOOR** IN,
ATTACH THE **HANDLE**.

STANDARD




3 **LOGS** IN PLACE



DON`T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.

STANDARD





INSTALL THE **GABLES** WITH **LONG SCREWS**
TO THE WALL LOGS ON THE FRONT AND
REAR WALLS.

6x140



Ø 5 mm





STANDARD


INSTALL THE **ROOF** PURLINS AND
ATTACH THEM WITH SCREWS.

6x140


Ø 5 mm



STANDARD



PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE **END** OF THE PURLINS AND ATTACH WITH 8 SCREWS, 4 **INTO** EACH NEXT.





STANDARD



FOR THE FASCIA TRIMS
INSERT **SCREWS** AFTER
EVERY 0,5 METERS.

STANDARD

4x40




EAVES EDGES GO ON TOP
OF THE ROOFING*.



*(NOT INCLUDED)

4x40

Ø 3 mm



STANDARD





ATTACH ROMB WITH SCREWS.


STANDARD

4x40
Ø 3 mm


ROMB




DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.



STANDARD






WINDBOARD




IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90° .

STANDARD



IF **DOORS** ARE IN DIFFERENT HEIGHTS
OR THERE IS A GAP **BETWEEN** THEM,
ADJUST 3 SCREWS ON DOOR HINGES.

STANDARD



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

STANDARD

