







PREPARE THE GROUND, UNWRAP THE PACKAGE,
LAY OUT THE COMPONENTS, FIND THE TOOLS.

BENTE IV 28



4x40 × 65

4x50 × 470


5x70 × 10

6x140 × 35


M8x60 × 12

1,4x40 × 35

LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.



BENTE IV 28





MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%

LAY OUT THE **BOTTOM** LOGS,
ATTACH TO THE FOUNDATION.



BENTE IV 28

5×70 \times 5 6×140 \times 16
 \varnothing 4 mm \varnothing 5 mm





THE WALL **LOGS** WILL HANG OVER
THE FOUNDATION **BEAMS** BY
APPROXIMATELY 5MM. THIS OVERHANG
IS DESIGNED AS A RAIN DRIP. **5%**

ATTACH THE FIRST ROW OF
WALL LOGS INTO THE BOTTOM
LOGS WITH **SCREWS**.




BENTE IV 28





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

BENTE IV 28




SLIDE THE DOOR IN,
ATTACH THE HANDLE.

BENTE IV 28



DON`T FORGET TO
TIGHTEN THE LOGS AFTER
EVERY 3-4 ROWS.


BENTE IV 28



INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

BENTE IV 28



6x140 × 4
Ø 5 mm



INSTALL THE **ROOF** PURLINS AND **ATTACH** THEM WITH SCREWS.

BENTE IV 28



6x140 × 6
Ø 5 mm



PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE
END OF THE **PURLINS** AND ATTACH
WITH 6 SCREWS, 3 INTO **EACH** NEXT,
SAW THE LAST **BOARD** TO MAKE IT FIT.

4x50
× 234



BENTE IV 28



FOR THE FASCIA TRIMS INSERT
SCREWS AFTER EVERY 0,5 METERS.

BENTE IV 28

4x40
× 36




EAVES EDGES GO ON TOP OF THE ROOFING*.

*(NOT INCLUDED)

BENTE IV 28



4x40 × 24


Ø 3 mm



ATTACH ROMBS WITH SCREWS.


BENTE IV 28

4×40  $\times 4$
 $\varnothing 3 \text{ mm}$ 





16 SCREWS INTO THE FIRST FLOORBOARD,
8 INTO EACH NEXT, SAW THE
LAST BOARD TO MAKE IT FIT.

4x50
× 224





BENTE IV 28




SAW THE **BASEBOARDS**
AND ATTACH WITH NAILS
AT **EVERY 0,5** METERS.

1,4×40
× 35





BENTE IV 28




DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x60 × 12

Ø 8 mm





BENTE IV 28



WINDBOARD


IF DOOR IS TILTED,
PUSH THE DOOR FRAME SO
THAT ALL CORNERS ARE 90° .

BENTE IV 28



IF **DOORS** ARE IN DIFFERENT HEIGHTS
OR THERE IS A GAP **BETWEEN** THEM,
ADJUST 3 SCREWS ON DOOR HINGES.

BENTE IV 28



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

BENTE IV 28

