




PREPARE THE GROUND, UNWRAP THE PACKAGE,  
LAY OUT THE COMPONENTS, FIND THE TOOLS.

# ARBOGA II 40



4x40 × 65

4x50 × 850



5x70 × 60

6x140 × 110



M8x70 × 15

1,4X40 × 40

LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.




ARBOGA II 40







MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%



# ATTACH FOUNDATION BEAMS WITH SCREWS.

# ARBOGA II 40


- $5 \times 70$    $\times 2$
- $6 \times 140$    $\times 10$
- $\varnothing 4 \text{ mm}$  
- $\varnothing 5 \text{ mm}$  



LAY OUT THE BOTTOM LOGS SO,  
THAT DOOR **OPENING** WILL BE  
**1441 MM** WIDE





ARBOGA II 40



ATTACH LOGS TO THE FOUNDATION.

$5 \times 70 \times 6$   
 $6 \times 140 \times 12$   
 $\varnothing 4 \text{ mm}$   
 $\varnothing 5 \text{ mm}$






ARBOGA II 40

THE WALL LOGS WILL HANG OVER THE FOUNDATION BEAMS BY APPROXIMATELY 5MM. THIS OVERHANG IS DESIGNED AS A RAIN DRIP. 6%

ATTACH THE NEXT ROW OF WALL LOGS INTO THE BOTTOM LOGS WITH SCREWS.


$5 \times 70$   $\times$  3  $6 \times 140$   $\times$  6  
 $\varnothing$  4 mm  $\varnothing$  5 mm



ARBOGA II 40


AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

ARBOGA II 40




SLIDE THE DOOR IN,  
ATTACH THE HANDLE.

# ARBOGA II 40




DON`T FORGET TO  
**TIGHTEN** THE LOGS AFTER  
EVERY 3-4 ROWS.

# ARBOGA II 40




SLIDE THE **WINDOWS** IN,  
ATTACH THE **HANDLE**.

ARBOGA II 40




# ARBOGA II 40



INSTALL **CEILING** TRIANGLE  
AND **ATTACH** WITH SCREWS  
INTO THE WALLS.

4x50 × 6    5x70 × 5

ARBOGA II 40



CEILING  
DETAIL  
40x120

CEILING  
TRIANGLE



LEAVE 4CM GAP BETWEEN  
DOOR AND **CEILING** DETAIL,  
**ATTACH** IT INTO **WALLS** AND INTO  
CEILING TRIANGLE USING SCREWS **47%**

ATTACH TOP LOGS INTO WALL LOGS WITH SCREWS.

ARBOGA II 40



6x140 × 40

Ø 5 mm




CONNECT THE ROOF PURLINS (RFR) WITH RD BEFORE INSTALLING THEM ON TOP OF THE CORNERS.

ARBOGA II 40




INSTALL THE **ROOF** PURLINS AND ATTACH THEM WITH SCREWS.

6x140 × 4  
Ø 5 mm




ARBOGA II 40



INSTALL THE ROOF PURLINS (RFB) AND ATTACH THEM WITH SCREWS.


$5 \times 70$   $\times 16$   $6 \times 140$   $\times 16$   $\varnothing 5 \text{ mm}$

$\varnothing 4 \text{ mm}$



16/24

ARBOGA II 40





58%

PLACE THE FIRST ROOFBOARD FLUSH WITH THE END OF THE PURLINS AND ATTACH WITH SCREWS

4x50 × 408



ARBOGA II 40






RB21

INSTALL THE ROOF TOP AND ATTACH IT WITH SCREWS. ATTACH FASCIA TRIMS INTO ROOFPURLINS.


ARBOGA II 40

4x40 × 56





SCREW THE **FLOORBOARDS** INTO FOUNDATION, SAW THE LAST **BOARD** TO MAKE IT FIT.

4x50  × 288




ARBOGA II 40



SAW THE **BASEBOARDS**  
AND ATTACH WITH NAILS  
AT **EVERY 0,5** METERS.

1,4X40  
× 40





ARBOGA II 40


DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x70 × 15

Ø 8 mm






ARBOGA II 40



WINDBOARD


IF DOOR IS TILTED,  
PUSH THE DOOR FRAME SO  
THAT ALL CORNERS ARE  $90^\circ$ .

# ARBOGA II 40



IF **DOORS** ARE IN DIFFERENT HEIGHTS OR THERE IS A GAP **BETWEEN** THEM, **ADJUST** 3 SCREWS ON DOOR HINGES.

# ARBOGA II 40



WHEN THE HOUSE IS ASSEMBLED, YOU SHOULD COVER THE TIMBER WITH WOOD PROTECTIVE SEAL, PAINT OR STAIN AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE WOOD.

ARBOGA II 40

